

ECBT2.E101723 - Connectors for Use in Data, Signal, Control and Power Applications - Component

Note: We are enhancing our systems and you may notice duplicate entries/missing/outdated data. During this interim period, please contact our Customer Service at <https://www.ul.com/about/locations>.

Connectors for Use in Data, Signal, Control and Power Applications - Component

INARCA SPA

Via Ca'zusto 35
Vigodarzere, Pd 35010 Italy

E101723

Marking: Company name or trademark  ,  ,  inarca ,  ,  ,  inarca , and model designation.

Note: For additional marking information, refer to the [Guide Information Page](#).

Component Connector, Model(s): INAR RAST 2.5, INAR RAST 2.5 ENERGY, INAR RAST 5 Timer Contact

Component Connector, "Inar Lock CS", Model(s): 54 followed by 90001 through 90004, 90013 through 90015, 90019 through 90022, 90006, 90031, 90007 through 90010, 90016 through 90018, 90012, 90042 through 90049, or 90050 through 90057, 90060, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Inar Lock CS", Model(s): 55 f/b followed by 90001 through 90004, 90013 through 90015, 90019 through 90022, 90006, 90031, 90007 through 90010, 90016 through 90018, 90012, 90042 through 90049, or 90050 through 90057, 90060, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Inar Lock CS", Model(s): 63 f/b followed by 90001 through 90004, 90013 through 90015, 90019 through 90022, 90006, 90031, 90007 through 90010, 90016 through 90018, 90012, 90042 through 90049, or 90050 through 90057, 90060, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Inar Lock CS", Model(s): 64 followed by 90001 through 90004, 90013 through 90015, 90019 through 90022, 90006, 90031, 90007 through 90010, 90016 through 90018, 90012, 90042 through 90049, or 90050 through 90057, 90060, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Inar MiniLock Connectors", Model(s): 54 followed by 52036, 52037, 52038, 52039, 52040, 52041, 52042, 52043, followed by 52048, 52049, 52050, 52051, 52052, 52053, 52054, 52055, 52056, 52057, 52058, 52059, 52060, 52061 or 52062, followed by 70 or 75, followed by one number.

Component Connector, "Inar MiniLock Connectors", Model(s): 63 followed by 52036, 52037, 52038, 52039, 52040, 52041, 52042, 52043, followed by 52048, 52049, 52050, 52051, 52052, 52053, 52054, 52055, 52056, 52057, 52058, 52059, 52060, 52061 or 52062, followed by 70 or 75, followed by one number.

Component Connector, "Inar MiniLock Connectors", Model(s): 64, followed by 52036, 52037, 52038, 52039, 52040, 52041, 52042, 52043, followed by 52048, 52049, 52050, 52051, 52052, 52053, 52054, 52055, 52056, 52057, 52058, 52059, 52060, 52061 or 52062, followed by 70 or 75, followed by one number.

Component Connector, "Inar Safety", Model(s): 0863314700, 0863328710, 6452008700

Component Connector, "INAR-IDC", Model(s): Rast 5 PCB

Component Connector, "Series Inar Lock Universal", Model(s): 0854 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Series Inar Lock Universal", Model(s): 0855 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Series Inar Lock Universal", Model(s): 0863 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Series Inar Lock Universal", Model(s): 0864 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Series Inar Lock Universal", Model(s): 54 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Series Inar Lock Universal", Model(s): 55 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component connectors, Model(s): Inar Safety

Connectors, "Inar-Edge", Model(s): 0854 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "Inar-Edge", Model(s): 0863 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "Inar-Edge", Model(s): 0864 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "Inar-Edge", Model(s): 54 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "Inar-Edge", Model(s): 63 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "Inar-Edge", Model(s): 64 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "INAR-LI 6.3", Model(s): 0864 or 0863 f/b 314, 328, 329, 52029, 52030, 52031, 52032, 52075, 52180, 315, 340, 316, 317, 318, 52072, followed by 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87 or 88, followed by one number.

Connectors, "INAR-LI 6.3", Model(s): 64 or 63 f/b 314, 328, 329, 52029, 52030, 52031, 52032, 52075, 52180, 315, 340, 316, 317, 318, 52072, followed by 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87 or 88, followed by one number.

Connectors, "Inar-TC", Model(s): 0864 f/b 177, 178, 263, 50363, 52077

Connectors, "Inar-TC", Model(s): 0854 followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Inar-TC", Model(s): 0854 or 54 f/b 177, 178, 263, 50363, 52077 followed by 70 or 76, followed by one number

Connectors, "Inar-TC", Model(s): 0855 followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Inar-TC", Model(s): 0855 or 55 f/b 177, 178, 263, 50363, 52077

Connectors, "Inar-TC", Model(s): 0864 followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Inar-TC", Model(s): 0864, followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Inar-TC", Model(s): 54 followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Inar-TC", Model(s): 55 followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Multiple Direct", Model(s): 0854 or 0864 followed by 009 to 018, 022, 023, 028, 031, 081, 090, 136, 52117, 52104, 52105, 52106, 52107, 52108, 52109, 52110, 52111, 52112, 52113, 52114, 52125, 52120, 52121, 52116, 293, 50357, 50358, followed by 70 or 74, followed by one number.

Connectors, "Multiple Direct", Model(s): 0863 or 63 followed by 009 to 018, 022, 023, 028, 031, 081, 090, 136, 52117, 52104, 52105, 52106, 52107, 52108, 52109, 52110, 52111, 52112, 52113, 52114, 52125, 52120, 52121, 52116, 293, 50357, 50358, followed by 70 or 74, followed by one number.

Connectors, "TABS HOUSING RAST 5", Model(s): 0864 followed by 293, 295, 142, 52027, 088, 135, 086, 089, 136, 267, 319, 52028 or 52071, followed by 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87 or 88, followed by one number.

Connectors, "TABS HOUSING RAST 5", Model(s): 64 followed by 293, 295, 142, 52027, 088, 135, 086, 089, 136, 267, 319, 52028 or 52071, followed by 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87 or 88, followed by one number.

Crimp Contacts, Model(s): 0010689201, 0010980201, 0010981001, 0010981201, 0011364201, 0011365201, 0011585101, 0011586101, 0011587101, 0011588101, 0011589101, 0011590101, 0011636001, 0011636201, 10267, 10375, 10834, 10934, 10935, 11060, 11067, 11100, 11116, 11213, 11333

Crimp Contacts, "Inar-Edge", Model(s): 0011141101, 0011341101

ECBT8.E101723 - Connectors for Use in Data, Signal, Control and Power Applications Certified for Canada - Component

Note: We are enhancing our systems and you may notice duplicate entries/missing/outdated data. During this interim period, please contact our Customer Service at <https://www.ul.com/about/locations>.


Connectors for Use in Data, Signal, Control and Power Applications Certified for Canada - Component

INARCA SPA

Via Ca'zusto 35
Vigodarzere, Pd 35010 Italy

E101723

Marking: Company name or trademark  ,  ,  inarca ,  ,  ,  inarca , model designation, and the Recognized

Component Mark for Canada 

Note: For additional marking information, refer to the [Guide Information Page](#).

Component Connector, Model(s): INAR RAST 2.5, INAR RAST 2.5 ENERGY, INAR RAST 5 Timer Contact

Component Connector, "Inar Lock CS", Model(s): 54 followed by 90001 through 90004, 90013 through 90015, 90019 through 90022, 90006, 90031, 90007 through 90010, 90016 through 90018, 90012, 90042 through 90049, or 90050 through 90057, 90060, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Inar Lock CS", Model(s): 55 f/b followed by 90001 through 90004, 90013 through 90015, 90019 through 90022, 90006, 90031, 90007 through 90010, 90016 through 90018, 90012, 90042 through 90049, or 90050 through 90057, 90060, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Inar Lock CS", Model(s): 63 f/b followed by 90001 through 90004, 90013 through 90015, 90019 through 90022, 90006, 90031, 90007 through 90010, 90016 through 90018, 90012, 90042 through 90049, or 90050 through 90057, 90060, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Inar Lock CS", Model(s): 64 followed by 90001 through 90004, 90013 through 90015, 90019 through 90022, 90006, 90031, 90007 through 90010, 90016 through 90018, 90012, 90042 through 90049, or 90050 through 90057, 90060, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Inar MiniLock Connectors", Model(s): 54 followed by 52036, 52037, 52038, 52039, 52040, 52041, 52042, 52043, followed by 52048, 52049, 52050, 52051, 52052, 52053, 52054, 52055, 52056, 52057, 52058, 52059, 52060, 52061 or 52062, followed by 70 or 75, followed by one number.

Component Connector, "Inar MiniLock Connectors", Model(s): 63 followed by 52036, 52037, 52038, 52039, 52040, 52041, 52042, 52043, followed by 52048, 52049, 52050, 52051, 52052, 52053, 52054, 52055, 52056, 52057, 52058, 52059, 52060, 52061 or 52062, followed by 70 or 75, followed by one number.

Component Connector, "Inar MiniLock Connectors", Model(s): 64, followed by 52036, 52037, 52038, 52039, 52040, 52041, 52042, 52043, followed by 52048, 52049, 52050, 52051, 52052, 52053, 52054, 52055, 52056, 52057, 52058, 52059, 52060, 52061 or 52062, followed by 70 or 75, followed by one number.

Component Connector, "Inar Safety", Model(s): 0863314700, 0863328710, 6452008700

Component Connector, "INAR-IDC", Model(s): Rast 5 PCB

Component Connector, "Series Inar Lock Universal", Model(s): 0854 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Series Inar Lock Universal", Model(s): 0855 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Series Inar Lock Universal", Model(s): 0863 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Series Inar Lock Universal", Model(s): 0864 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Series Inar Lock Universal", Model(s): 54 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component Connector, "Series Inar Lock Universal", Model(s): 55 followed by 050, 052, 054, 056, 058, 060, 062, 064, 066, 069, 080, 50397, 50398, 051, 053, 055, 057, 059, 061, 063, 065, 067, 079, 50372 or 50393, followed by 70, 79 or 75, followed by one number, may be followed by A.

Component connectors, Model(s): Inar Safety

Connectors, "Inar-Edge", Model(s): 0854 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "Inar-Edge", Model(s): 0863 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "Inar-Edge", Model(s): 0864 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "Inar-Edge", Model(s): 54 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "Inar-Edge", Model(s): 63 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "Inar-Edge", Model(s): 64 followed by 085, 091, 092, 093, 094, 095, 096, 097, 098, 099, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 152, 153, 156, 157, 158, 159, 160, 161, 164, 285, 298, 299, 300, 301, 338, 50394, 50399, 52023, 52141 or 52149, followed by 700, may be followed by HB.

Connectors, "INAR-LI 6.3", Model(s): 0864 or 0863 f/b 314, 328, 329, 52029, 52030, 52031, 52032, 52075, 52180, 315, 340, 316, 317, 318, 52072, followed by 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87 or 88, followed by one number.

Connectors, "INAR-LI 6.3", Model(s): 64 or 63 f/b 314, 328, 329, 52029, 52030, 52031, 52032, 52075, 52180, 315, 340, 316, 317, 318, 52072, followed by 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87 or 88, followed by one number.

Connectors, "Inar-TC", Model(s): 0864 f/b 177, 178, 263, 50363, 52077

Connectors, "Inar-TC", Model(s): 0854 followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Inar-TC", Model(s): 0854 or 54 f/b 177, 178, 263, 50363, 52077 followed by 70 or 76, followed by one number

Connectors, "Inar-TC", Model(s): 0855 followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Inar-TC", Model(s): 0855 or 55 f/b 177, 178, 263, 50363, 52077

Connectors, "Inar-TC", Model(s): 0864 followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Inar-TC", Model(s): 0864, followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Inar-TC", Model(s): 54 followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Inar-TC", Model(s): 55 followed by 134, 172, 174, 175, 171, 258, 259, 180, 226, 243, 265, 173, 323, 297, 279, 176, 260, 261, 264, 284, 290, 312, 049, 189, 262, 50387, 52065, 50388, 50362, 52074, 50351, 52015, 52064, 50386, 52021 or 254, followed by 70 or 76, followed by one number.

Connectors, "Multiple Direct", Model(s): 0854 or 0864 followed by 009 to 018, 022, 023, 028, 031, 081, 090, 136, 52117, 52104, 52105, 52106, 52107, 52108, 52109, 52110, 52111, 52112, 52113, 52114, 52125, 52120, 52121, 52116, 293, 50357, 50358, followed by 70 or 74, followed by one number.

Connectors, "Multiple Direct", Model(s): 0863 or 63 followed by 009 to 018, 022, 023, 028, 031, 081, 090, 136, 52117, 52104, 52105, 52106, 52107, 52108, 52109, 52110, 52111, 52112, 52113, 52114, 52125, 52120, 52121, 52116, 293, 50357, 50358, followed by 70 or 74, followed by one number.

Connectors, "TABS HOUSING RAST 5", Model(s): 0864 followed by 293, 295, 142, 52027, 088, 135, 086, 089, 136, 267, 319, 52028 or 52071, followed by 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87 or 88, followed by one number.

Connectors, "TABS HOUSING RAST 5", Model(s): 64 followed by 293, 295, 142, 52027, 088, 135, 086, 089, 136, 267, 319, 52028 or 52071, followed by 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87 or 88, followed by one number.

Crimp Contacts, Model(s): 0010689201, 0010980201, 0010981001, 0010981201, 0011364201, 0011365201, 0011585101, 0011586101, 0011587101, 0011588101, 0011589101, 0011590101, 0011636001, 0011636201, 10267, 10375, 10834, 10934, 10935, 11060, 11067, 11100, 11116, 11213, 11333

Crimp Contacts, "Inar-Edge", Model(s): 0011141101, 0011341101

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL Solutions' Follow - Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL Solutions' Follow - Up Service. Always look for the Mark on the product.

UL Solutions permits the reproduction of the material contained in Product iQ subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from Product iQ with permission from UL Solutions" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "©2022 UL LLC."